

How to switch between Model 308 and 316

1) Check whether the controller is on the Independent Working Mode



1-1) If the logo is with the **yellow** color, it means the controller is on the **Independent Working Mode**, then we can go to Step 2);

1-2) If the logo is with **blue/violet** color, it means the controller is on the **group leader working mode/group member working mode**, in this case, it needs to switch to **Independent Working Mode** firstly, and the methods is:



Press the switch button for 3 seconds, it goes into working mode status; Press again the switch button, it changes the working mode, when the logo color turns **yellow**, meaning it is on the **Independent Working Mode**, then press the switch button for 3 seconds to save the mode setting.

2) On the **Independent Working Mode**, Press and hold the dial button and switch button for 3 seconds, the logo color will turn **red** or **green**, **red** means it is Model 308, **green** means it is Model 316.



3) If the logo turns **red** at step 2, it indicates that it's the 308 model. If your pump is the 316 model, then you need to change it by long pressing the switch button. When the logo switches to **green**, it means the model has been successfully changed to the 316.

and same, if logo color is **green** on Step 2), means it is Model 316, and you need to switch it to 308, you can long press the switch button, when logo strobes **red**, it means the model number has been switched to 308;



4) After you get your model number from Step 2) or 3), power off the controller, then power it on again, to confirm its model number. The logo strobes twice, it is Model 308, the logo strobes 4 times, it is Model 316.